

























COSADE

Huecos de junquillos

Junquillo	Serie	A96/A96R/ C2002/ 2000 EURO	A94/A94R/C94/ C97/C97R/ CE29R	A10R	AR25	A98R	A11R/ A11RC16	AR21/ HO12R(*)	A14R/ A14RC16	A14RE2/ A14RE2C16
4mm	 515399	32,5	36	37,5	41	45	46,5	53,5	54,5	68,5
12mm	 52244  52517  52005	24,5	28	29,5	33	37	38,5	45,5	46,5	60,5
16mm	 52440  52516  52384	20,5	24	25,5	29	33	34,5	41,5	42,5	56,5
20mm	 52243  54155  52515  52004	16,5	20	21,5	25	29	30,5	37,5	38,5	52,5
24mm	 52972  52971  54808	12,5	16	17,5	21	25	26,5	33,5	34,5	48,5
26mm	 52779	10,5	14	15,5	19	23	24,5	31,5	32,5	46,5
28mm	 52242  52514  52003	8,5	12	13,5	17	21	22,5	29,5	30,5	44,5
33mm	 54215  54323		7	8,5	12	16	17,5	24,5	25,5	39,5
36mm	 52059				9	13	14,5	21,5	22,5	36,5
40mm	 517437					9	10,5	17,5	18,5	32,5

(*) Considerar junta de acristalar exterior para el hueco en la serie HO12R.